アニメーションタブ

Animation Tab



アニメーションタブのコントロール説明

① アニメーション GIF の作成　別途説明

② アニメーション GIF の作成　別途説明

③ 外部の GIF の読込

④ GIF 画像

⑤ GIF 画像のサイズ

⑥ アニメーションの動作の停止

⑦ ＧＩＦ保存フォルダーを開ける

⑧ ＧＩＦをサーバーに転送

⑨ ＧＩＦを音楽付きでサーバーに転送

⑩ ＦＴ８で送信

⑪ 緊急停止

ＧＭＳＫ送信は　Vari Image Front の
*** GMSK TX *** を押す

その他のファイルの送信、受信

⑫ ファイルの読み込み　なんでも OK です

⑬ その読込ファイルを開く

⑭ サーバーに転送する

⑮ FT8 で送信する。 GMSK の場合は Vari Image Front の*** GMSK TX *** を押す。

⑯ 受信ファイルのリフレッシュ

⑰ 受信ファイルのリスト　拡張子はそれぞれに対応して表示される。　.xxx と表示された場合は判定不能です。

⑱ 保存フォルダーを開く

⑲ ファイルを削除

⑳ ⑰のファイルを選び拡張子を表示する。ない場合は拡張子をインプットする。

㉑ 選ばれたファイルを開く



Animation tab control description

① Creation of animated GIF Separate explanation

② Creation of animated GIF Separate explanation

③ Loading external GIF

④ GIF image

⑤ GIF image size

⑥ Stopping the animation operation

⑦ Open the GIF storage folder

⑧ Transfer GIF to server

⑨ Transfer GIF with music to server

⑩ Send with FT8

⑪ Emergency stop

GMSK transmission is done by Vari Image Front. Press *** GMSK TX ***

Sending and receiving Any Files

⑫ Loading the file, Anything is OK.

⑬ Open file to read

⑭ Transfer to server

⑮ Send using FT8. For GMSK, press *** GMSK TX *** on Vari Image Front.

⑯ Refreshing the received file

⑰ List of received files. The extensions are displayed corresponding to each file. If .xxx is displayed, it cannot be determined.

⑱ Open the save folder

⑲ Delete file

⑳ Select the file in ⑰ and display the extension. If not, enter the extension.

㉑ Open the selected file